

Modelo	Trans. Popa	Tran. Pas.Br.	Tran.Pas.Pla	Pasac. Bajo perfil	Triducer Pas	Trolling Motor	Tr. V/T popa	Tr.V/T Pas	C.Alim.	Caja portatil
Piranha MAX 210 / 220 / 150 / 170 / 190	XNT-9-20-T	XTH-9-20	XTH-9-20-P	XFM-9-20	No disponible	XTM-9-20	No disponible	No disponible	PC-10	PTC-P
Piranha MAX 10 / 20	XNT-9-20-T	XTH-9-20	XTH-9-20-P	XFM-9-20	No disponible	XTM-9-20	No disponible	No disponible	PC-10	PTC-P
Piranha MAX 143 / 153 / 195	XNT-9-20-T	XTH-9-20	XTH-9-20-P	XFM-9-20	No disponible	XTM-9-20	No disponible	No disponible	PC-10	PTC-P
Piranha MAX 176 / 196	XNT-9-28-T	No disponible	No disponible	No disponible	No disponible	XTM-9-28-T	No disponible	No disponible	PC-10	PTC-P
Piranha MAX 155 / 165 / 197 C	XNT-9-20-T	XTH-9-20	XTH-9-20-P	XFM-9-20	No disponible	XTM-9-20	No disponible	No disponible	PC-10	
Piranha MAX 197 DI	XNT-9-DI-T	No disponible	XPTH-9-DI-T	No disponible	No disponible	XTM-9-DI-25-T	No disponible	No disponible	PC-10	
141 / 323 / 343 / 363 / 383	XNT-9-20-T	XTH-9-20	XTH-9-20-P		No disponible	XTM-9-20	TS-W	TS WFM	PC-10	PTC-U
325 / 345 / 365 / 385 / 386	XNT-9-20-T	XTH-9-20	XTH-9-20-P	XFM-9-20	No disponible	XTM-9-20	TS-W	TS WFM	PC-10	PTC-U
346 DI	XNT-9-DI-T	No disponible	XPTH-9-DI-T	No disponible	No disponible	XTM-9-DI-25-T	No disponible	No disponible	PC-10	PTC-U
398	XHS-9-HDSI-180 T	No disponible	XPTH-9-HDSI-180-T	No disponible	No disponible	XTM-9-SI-180T	TS-W	TS-WFM	TS-WFM	PTC-U
Helix 5 / helix GPS /	XNT-9-20-T	XTH-9-20	XTH-9-20-P		No disponible	XTM-9-20	TS-W	TS WFM	PC-11	PTC-U
Helix DI / Helix 5 GPS DI	XNT-9-DI-T	No disponible	XPTH-9-DI-T	No disponible	No disponible	XTM-9-DI-25-T	TS-W	TS-WFM	PC-11	PTC-U
Helix 5 SI	XHS-9-HDSI-180 T	No disponible	XPTH-9-HDSI-180-T	No disponible	No disponible	XTM-9-SI-180T	TS-W	TS-WFM	PC-11	No disponible
HELIX 5 XD	XNT-9-DB-74-T	No disponible	XTH-9-DB-74-P	No disponible	No disponible	No disponible	TS-W	TS-WFM	PC-11	No disponible
FF 515 / 525 / 535 / 565 / 585 / 595	XNT-9-20-T	XTH-9-20	XTH-9-20-P	XFM-9-20	No disponible	XTM-9-20	TS-W	TS WFM	PC-10	PTC-U
550 / 560 / 570 / 586 / 587 525 /	XNT-9-20-T	XTH-9-20	XTH-9-20-P	XFM-9-20	No disponible	XTM-9-20	TS-W	TS WFM	PC-10	PTC-U
561 / 541 / 587	XNT-9-20-T	XTH-9-20	XTH-9-20-P	XFM-9-20	No disponible	XTM-9-20	TS-W	TS WFM	PC-10	PTC-U
571 DI / 597 DI	XNT-9-DI-T	No disponible	XPTH-9-DI-T	No disponible	No disponible	XTM-9-DI-25-T	TS-W	TS-WFM	PC-10	PTC-U
598	XHS-9-HDSI-180 T	No disponible	XPTH-9-HDSI-180-T	No disponible	No disponible	XTM-9-SI-180T	TS-W	TS-WFM	PC-10	PTC-U
597 XD	XNT-9-DB-74-T	No disponible	XTH-9-DB-74-P	No disponible	No disponible	No disponible	TS-W	TS-WFM	PC-10	PTC-U
678 / 688 CXI HD /	XNT-9-20-T	XTH-9-20	XTH-9-20-P	XFM-9-20	No disponible	XTM-9-20	TS-W	TS WFM	PC-11	No disponible
678 CX HD DI / 688 CX HD DI	XNT-9-DI-T	No disponible	XPTH-9-DI-T	No disponible	No disponible	XTM-9-DI-25-T	TS-W	TS-WFM	PC-11	No disponible
688 CXI HD XD	XNT-9-DB-74-T	No disponible	XTH-9-DB-74-P	No disponible	No disponible		TS-W	TS-WFM	PC-11	No disponible
698 SI	XHS-9-HDSI-180 T	No disponible	XPTH-9-HDSI-180-T	No disponible	No disponible	XTM-9-SI-180T	TS-W	TS-WFM	PC-11	No disponible
718 / 728 / 778 / 788	XNT-9-20-T	XTH-9-20	XTH-9-20-P	XFM-9-20	No disponible	XTM-9-20-T	TS-W	TS-WFM	PC-10	No disponible
727 / 767 / 777 / 787	XNT-9-20-T	XTH-9-20	XTH-9-20-P	XFM-9-20	No disponible	XTM-9-20	TS-W	TS-WFM	PC-10	No disponible

